

Energizer®



**DRILL HEAD FOR
ECOMOTION MULTIFUNCTION BASE
ECO0
USER GUIDE**

CAUTION: Read this manual before using this unit!




Energizer®

©2022 Energizer. Energizer and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Builder SAS. All other brand names are trademarks of their respective owners. Neither Builder SAS nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks.

Let's get started.

You're excited to power up, so we'll keep this brief!

! **WARNING:** All safety instructions and technical data are included in the manual for ECOMOTION multifunction tool, please read it before using this unit!

	Conforms to relevant safety standards
	To reduce the risk of injury, the user must read and understand this manual before using this product.
	Do not dispose of old appliances with domestic rubbish.

1. PART DESCRIPTION



- 1) Keyless chuck
- 2) Torque adjustment ring
- 3) Gear selector
- 4) Fitting joint

2. Fitting the drill head with ECOMOTION multifunction base:

- 1) Push the drill head along the guide rail into the multifunction base. It locks into place audibly.
- 2) Allow the unlocking lever on base to slide back into position.
- 3) Check drill head is secure by pulling on it.

3. Fitting a drill or screw bit

- 1) Rotate the keyless chuck counterclockwise, until the drill chuck aperture is large enough to accommodate drill or screw bit.
- 2) Insert the drill or screw bit as far as possible into the keyless chuck.
- 3) Rotate the keyless chuck (1) clockwise in order to clamp the tool.
- 4) To remove the tool again, rotate the keyless chuck (1) and pull out the tool.

4. Choice of gear

! **WARNING!** Stop appliance before changing gear to avoid tool damage.

- 1) Wait for the appliance to come to a standstill.
- 2) Slide the gear selector into the required position:


- a) L=> low speed
- b) H=> high speed


5. Set the direction of rotation

The appliance's direction of rotation can be changed with the rotational direction switch.

- 1) Wait for the appliance to come to a standstill.
- 2) Push the rotational direction speed on ECOMOTION multifunction base into the desired position:
 - a) Clockwise rotation: to drill and screw in screws.
 - b) Counterclockwise rotation: to unscrew screws.
 - c) If you place the direction switch in the middle position, the device is secured against being switched on.

6. Torque adjustment

You can preselect the maximum torque, the torque settings are labeled 1—22 + 

- 1) Wait for the appliance to come to a standstill.
- 2) Turn the torque adjusting ring to select the desired torque:
 - a) Screws: Steps 1 – 22
 - b) Drilling: Step 
- 3) Start with a lower torque step and increase as required.

Note: The necessary torque is dependent on:

- The type and hardness of the material to be treated。
- The type and length of the screws used.

Energizer[®]