

# ***Energizer***®



**IMPACT DRIVER HEAD FOR  
ECOMOTION MULTIFUNCTION BASE  
ECO1  
USER GUIDE**

**CAUTION:** Read this manual before using this unit!




# ***Energizer®***

©2022 Energizer. Energizer and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Builder SAS. All other brand names are trademarks of their respective owners. Neither Builder SAS nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks.

## **Let's get started.**

You're excited to power up, so we'll keep this brief!

**!** **WARNING:** All safety instructions and technical data are included in the manual for ECOMOTION multifunction tool, please read it before using this unit!

|   |  |
|---|--|
|  | Conforms to relevant safety standards  |
|  | To reduce the risk of injury, the user must read and understand this manual before using this product. |
|  | Do not dispose of old appliances with domestic rubbish.  |

## 1. PART DESCRIPTION



- 1) Drive bit retaining ring
- 2) Fitting joint

## 2. Fitting the impact driver head with ECOMOTION multifunction base:

- 1) Push the impact driver head along the guide rail into the multifunction base. It locks into place audibly.
- 2) Allow the unlocking lever on base to slide back into position.
- 3) Check impact driver head is secure by pulling on it.

## 3. Fitting a driver bit or long adaptor bit

- 1) Pull the driver bit retaining ring forward.
- 2) Insert the adaptor/ bit.
- 3) Release the drive bit retaining ring, it will return to its normal position.
- 4) Select the direction of rotation.
- 5) Turn on the impact driver by depressing the variable speed on/off trigger.
- 6) Increased pressure on the trigger will increase the speed of the impact driver.



***Energizer***<sup>®</sup>